

COVER & CURTAINS: DRY CLEAN ONLY.



COVER REPLACEMENT WALL PANEL
MOTION, FLOOR SCREEN ROUNDED &
SQUARE, TABLE SCREEN ROUNDED &
SQUARE.

STEP 1:

Click off the top and under covers


STEP 2:

Unfold the edging at top and bottom

STEP 3:

Pull off the fabric

Re-attach in the opposite order



COVER REPLACEMENT
WALL PANEL ROUNDED & SQUARE:

STEP 1:

Dismantle the tightening strip

STEP 2:

Remove fabric

RE-ASSEMBLY:

STEP 1:

Attach the fabric. Start at the front

STEP 2:

Attach the tightening strip. Wrap the fabric
an extra time around the tightening strip if the
fabric needs to be stretched tighter.

